



HEATIZON
S Y S T E M S

MISCELLANEOUS KITS

- ENCLKIT** **Enclosure Kit**, 2' x 2' x 1' –Weatherproof NEMA enclosure comes complete with a back plate customized to mount Heatizon Systems Control Units and Transformers.
- JSTSCRKIT** **Joist Screen Kit** –Includes joist spacers and screws used to attach Z Mesh element to the underside of a sub-floor for retrofit Z Mesh applications. Available sizes: 100 feet, 250 feet, and 350 feet.
- CLDJNTKIT** **Joint Jumper Kit** – For jumpering under joints of any kind. Tuff Cable must never be allowed to extend through any joint. Kit contains four E210BS butt splices, two feet of E210 Cold Lead, solder, four 6" heat shrink lengths, two lengths protective flex device, and four 2" sleeves.
- CABSPLKIT** **Tuff Cable Splice Kit** – For splicing or repairing Tuff Cable that has been damaged or cut. Note: use a CABREPKIT when the break occurs within concrete or asphalt.
- CABREPKIT** **Tuff Cable Repair Kit** – For splicing or repairing Tuff Cable breaks in concrete or asphalt. Kit contains two #10 Butt Splice Connectors, one foot of solder, two 2-1/2" heat shrink lengths, two 4" lengths of copper tubing, two feet of Tuff Cable, four foam end plugs, and two 1 ½" chairs.
- PLASCLIPKIT** **Plastic Clip Kit** – For securing Tuff Cable in mortar bed. Kit will secure 100 feet of element.
- ANCHPLUGKIT** **Tuff Cable Anchoring Plug Kit** – For securing Tuff Cable in a mortar bed when placed on concrete. Includes 70 Tuff Cable Anchoring Plugs.
- PAVERKIT** **Paver Kit** – For securing Tuff Cable in a sand bed under pavers. Includes 50 7" wire ties and 50 3/8" x 10" spikes. Kit will secure 100 feet of element.
- CUTOUTKIT** **Z Mesh Cut Out Kit** – Must be used any time Z Mesh is cut to accommodate an object. Includes two 12" splice plates and solder.

Heatizon Systems
4403 South 500 West
Murray, UT 84123
www.heatizon.com



Phone (801) 293-1232
Fax (801) 293-3077
Toll Free (888) 239-1232